

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Бологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
Иваново (4932)77-34-06
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новобрянск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (353)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сыктывкар (8212)25-95-17
Сургут (3462)77-98-35
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://izon.nt-rt.ru> || inz@nt-rt.ru

Изоляционные колонки qEVORIGINAL

qEVORIGINAL USER MANUAL



SPECIFICATIONS AND OPERATIONAL
GUIDE FOR SMART COLUMNS

RAPID & RELIABLE PURIFICATION OF
EXTRACELLULAR VESICLES

Izon Science Ltd. provides this document to its customers with a product purchase to use in the product operation. This document is copyright protected and any reproduction of the whole or any part of this document is strictly prohibited, except with the written authorization of Izon Science Ltd.

The contents of this document are subject to change without notice. All technical information in this document is for reference purposes only. System configurations and specifications in this document supersede all previous information received by the purchaser.

Izon Science Ltd. makes no representations that this document is complete, accurate or error-free and assumes no responsibility and will not be liable for any errors, omissions, damage or loss that might result from any use of this document, even if the information in the document is followed properly.

This document is not part of any sales contract between Izon Science Ltd. and a purchaser. This document shall in no way govern or modify any Terms and Conditions of Sale, which Terms and Conditions of Sale shall govern all conflicting information between the two documents.

All third-party trademarks are the property of their respective owners.

TABLE OF CONTENTS

1	Definitions and Writing Conventions	4
2	Safety and Hazards	6
2.1	Hazards.....	6
2.2	Storage	8
2.3	Disposal	8
3	Introduction to Size Exclusion Chromatography	9
3.1	Overview.....	9
3.2	Intended Use	11
3.3	Comparison of qEV/35nm and qEV/70nm series	11
3.4	qEVoriginal Specifications	13
3.5	qEVoriginal Performance Characteristics.....	14
3.6	qEVoriginal EV Elution Profile.....	16
3.7	qEVoriginal Sample Input Volume Effects and Recovery Rates....	17
3.7.1	Effect of Sample Input Volume on EV Elution Profile	17
3.7.2 Effect of Resin Type on Protein Elution Profile	18
3.7.3	Effect of Sample Input Volume on EV Dilution and Recovery Rate...	18
4	Manual Operating Instructions.....	19
4.1	Operational Recommendations	19
4.2	Column Setup and Equilibration	21
4.3	Sample Loading	22
4.4	Column Flush and Storage.....	22
5	Resources	23
5.1	Column Cleaning and Sanitisation	23
5.2	Protocols for EV Isolation from Common Sources.....	23
5.3	EV Analysis Using TRPS	23

Make sure to follow the precautionary statements presented in this guide. Safety and other special notices will appear in boxes and include the symbols detailed below.

Table 1: Safety and Hazard Symbols



This symbol indicates general advice on how to improve procedures or recommends measures to take in specific situations.



This symbol indicates where special care should be taken.

Table 2: Terminology Used in this Manual

TERM	DEFINITION
Chromatography	A method used primarily for separation of the components of a sample. The components are distributed between two phases; one is stationary while the other one is mobile. The stationary phase is either a solid, a solid supported liquid, or a gel. The stationary phase may be packed in a column, spread as a layer or distributed as a film. The mobile phase may be gaseous or liquid.
Column volume	The combined volume of packed material and void volume (can be referred to as the bed volume).
Degassing	Degassing involves subjecting a solution to vacuum to “boil” off excess dissolved gas e.g. applying a vacuum to a flask.
EV zone	Indicates a particular volume collected from the column after the void volume, specified numerically for a given size. For example, 0.5 mL refers to the 0.5 mL volume collected after the void volume.
Flow rate	The volumetric flow in mL/min of the carrier liquid.
Protein zone	Indicates a particular volume collected from the column after the EV zone volume. This volume contains the majority of separated proteins.
Smart Column	A qEV column with an integrated RFID chip. This chip is used by the AFC instrument to recognize the type of column attached to the instrument. This chip does not affect manual usage of the qEV column.
Void volume	The total volume of mobile phase in the column; the remainder of the column is taken up by packed gel material. It denotes the excluded volume.
Recovery rate	The percentage of vesicles that come out of the column compared with what went in.

Refer to the Safety Data Sheet for the classification and labelling of hazards and associated hazard and precautionary statements. The Safety Data Sheet for qEV SMART columns is located at <http://www.izon.com/products/sds>

2.1 Hazards

qEV SMART columns are a laboratory product. However, if biohazardous samples are present, adhere to current Good Laboratory Practices (cGLP) and comply with any local guidelines specific to your laboratory and location.

Disposal of Biohazardous Material

The qEV SMART column contains < 0.1% sodium azide, which is potentially fatal if swallowed or in contact with skin. Please review the following guidelines and precautions prior to each use of the qEV SMART column:

Prevention:

1. Do not get into eyes, on skin, or on clothing.
2. Wash skin thoroughly after handling.
3. Do not eat, drink, or smoke when using this product.
4. Avoid release of product into the environment.
5. Wear protective gloves and clothing; follow general laboratory precautions.

Response

1. IF SWALLOWED: immediately call a POISON CONTROL CENTER/ Doctor.
2. IF ON SKIN: Gently wash with plenty of soap and water and immediately call a POISON CONTROL CENTER/Doctor.
3. Remove immediately any contaminated clothing and wash before reuse.
4. Collect any spillage and dispose of appropriately.

For more information, see the MSDS Documentation for Izon qEV SMART columns: <https://izon.com/sds/>



Sodium azide can be fatal if swallowed or in contact with skin. It can cause damage to neurological organs through prolonged or repeated exposure. It is very toxic to aquatic life with long lasting effects.

Be sure to adhere to the following guidelines and comply with any local guidelines specific to your laboratory and location regarding use and disposal.

General Precautions:

- Always wear laboratory gloves, coats, and safety glasses with side shields or goggles.
- Keep your hands away from your mouth, nose, and eyes.
- Completely protect any cut or abrasion before working with potentially infectious or hazardous material.
- Wash your hands thoroughly with soap and water after working with any potentially infectious or hazardous material before leaving the laboratory.
- Remove watches and jewellery before working at the bench.
- The use of contact lenses is not recommended due to complications that may arise during emergency eye-wash procedures.

- Before leaving the laboratory, remove protective clothing.
- Do not use a gloved hand to write, answer the telephone, turn on a light switch, or physically engage people without gloves.
- Change gloves frequently.
- Remove gloves immediately when they are visibly contaminated.
- Do not expose materials that cannot be properly decontaminated to potentially infectious or hazardous material.
- Upon completion of the tasks involving potentially infectious or hazardous materials, decontaminate the work area with an appropriate disinfectant or cleaning solution (1:10 dilution of household bleach is recommended).

Dispose of the following potentially contaminated materials in accordance with laboratory local, regional, and national regulations:

- Biological Samples
- Reagents
- Used reaction vessels or other consumables that may be contaminated

2.2 Storage

Rapid changes in temperature should be avoided, as this can introduce bubbles into the gel bed.

Store the column at +4 to +8 °C.

2.3 Disposal

Waste buffer should be disposed of in a safe manner. Sodium azide accumulation over time in copper pipes can result in an explosion.

INTRODUCTION TO SIZE EXCLUSION CHROMATOGRAPHY

3.1 Overview

Izon's qEV SMART Size exclusion chromatography (SEC) columns separate particles based on their size as they pass through column packed with a porous, polysaccharide resin. As molecules enter the resin, smaller particles become trapped in the pores and their exit from the column is delayed (Fig 1C). As liquid exits the column, sequential fractions are collected. Particles will be distributed across the fractions based on their size, with the largest particles exiting the column first and the smallest particles exiting the column last.

The packed column is equilibrated with a buffer, which fills the column. The total column volume is occupied by both the solid resin (stationary phase) and the liquid buffer (the mobile phase). As the particles do not bind to the resin, the buffer composition will not significantly affect the resolution (the degree of separation between peaks).




Figure 1: Process of SEC (A) Schematic picture of a resin bead with an electron microscopic enlargement. (B) Schematic drawing of sample molecules diffusing into the pores of the particle. (C) Graphical description of separation: (i) sample is applied to the column; (ii) the smallest particles (yellow) are more delayed than the largest particles (red); (iii) the largest particles are eluted first from the column. Band broadening causes significant dilution of the particle zones during chromatography. (D) Schematic chromatogram. From: GE Healthcare and Biosciences. (n.d.). Size Exclusion Chromatography Principles and Methods [Brochure]. Uppsala, Sweden. Accessed June 2019.

3.2 Intended Use

Izon qEV SMART columns isolate extracellular vesicles from biological samples. qEVoriginal SMART columns are equipped with RFID chips for use with the Izon Automated Fraction Collector (AFC). **These chips will not impact manual use.**

qEV SMART columns are designed to isolate and purify vesicles from most biological samples, including:

- Serum
- Plasma
- Saliva
- Urine
- Cerebrospinal Fluid (CSF)
- Cell culture media

NOTE: most 'raw' samples cannot be directly run on qEV SMART columns and analysed with TRPS without some preparation such as centrifugation and concentration steps. Contact the Izon Support Centre for recommendations and protocols.

3.3 Comparison of qEV/35nm and qEV/70nm series

All qEV SMART columns are available in one of two isolation ranges, the qEV/35nm series and the qEV/70nm series. The qEV/35nm series of columns generally perform better when the target particle to be isolated is less than 110 nm in diameter, while the qEV/70nm series of columns generally perform better when the target particle to be isolated is greater than 110 nm in diameter (see [Table 3](#)). For optimal recovery of particles between 35 and 350nm a qEV/35nm series column is recommended. For optimal recovery of particles between 70 and 1000nm a qEV/70nm series column is recommended.




Figure 2. Particle recovery by size for qEV-35 series column compared to qEV-70 series column (red line).

Table 3: Specifications of qEV/30nm and qEV/70nm Series

	qEV/35nm SERIES	qEV/70nm SERIES
Target Particle Size (nm)	35 to 350	70 to 1000
Optimum Recovery Range (nm)	Particles < 110	Particles > 110

3.4 qEOriginal Specifications

Table 4: qEOriginal Specification

Column name	qEORIGINAL	
Column series	qEORIGINAL -70nm	qEORIGINAL -35nm
Optimal separation size	Particles < 110	Particles > 110
Nominal flowrate (mL/min at 20°C)	1.0	0.6
Sample load volume	Up to 0.5 mL*	
Column volume (mL)	10	
Optimal fraction size (mL)	0.5	
Void volume (mL)	3	
Flush volume (mL)	15	
Nominal peak elution volume (mL)	1.5	
Elution peak after void (mL)	1 ± 0.5	
Operational temperature	18 to 24°C	
Buffer	PBS	
Largest size passable	1 µm	
Top and bottom filters size	20 µm	
pH stability working range	3 – 13	
pH stability cleaning-in-place (CIP)	2 – 14	
Shelf life (if stored correctly)	12 months	

3.5 qEVOriginal Performance Characteristics

As shown in [Figure 3 and 4 below](#), particles less than 70nm typically elute later than the EV zone on the qEV/70nm, whereas particles larger than 35nm are captured in this zone on the qEV/35nm column. A higher recovery in the EV zone of particles larger than 70nm occurs on the qEV-70 series columns compared with the qEV/35nm series ([Fig. 4](#)). Proteins typically elute slightly earlier on the qEV/35nm series. Higher protein levels in the EV zone are mainly due to an increase in EV bound proteins.




Figure 3: Comparison of total protein elution levels and recovery of 57nm particles between a qEVOriginal-35 and a qEVOriginal-70.




Figure 4: Comparison of total protein levels and recovery of 200nm particles between a qEVOriental-35 and a qEVOriental-70.

3.6 qEVOoriginal EV Elution Profile

The elution of vesicles typically peaks at 1 mL \pm 0.5 mL after the void volume, for a 0.5 mL sample volume and collecting 0.5 mL volumes. Figure 5 shows the elution of vesicles when 0.5 mL of plasma sample is loaded onto a qEVOoriginal-70 column.

The majority of EVs typically elute in 1.5 mL. If higher purity is desired, collect only the first 1 mL. The user therefore chooses between maximising recovery by collecting a larger volume or maximising purity by collecting a lesser volume.

The elution of plasma protein is slower, eluting predominantly from 2.5 – 7.0 mL after the void volume. Any vesicles recovered beyond 2 mL contain higher protein contamination and may be less suitable for downstream analysis because of their lower purity.

Indicative protein elution profiles can be obtained by monitoring the absorbance at a wavelength of 280nm. An accurate measurement of the level of protein can be obtained using a colorimetric protein assay.




Figure 5: Typical elution profile for a qEVOoriginal column with 0.5 mL of plasma loaded; proteins elute in a later volume than vesicles. The vesicle concentration was measured using a qNano and protein levels by absorbance at 280nm.

3.7 qEVO^{Original} Sample Input Volume Effects and Recovery Rates

3.7.1 Effect of Sample Input Volume on EV Elution Profile

Loading higher sample volumes results in a lower level of purity in the later vesicle volumes, greater overlap between protein and EV elution peaks, and a higher protein peak within the EV zone. Figure 6 shows the effect of loading plasma from 100 μL to 2000 μL . A sample volume of 2000 μL results in vesicles that are contaminated with higher amounts of protein when a typical 1.5 mL of the EV zone is collected. Note the delay in elution of EVs in the 2000 μL sample.

The optimal recommended sample volume for purity on the qEVO^{Original} is 200 μL to 500 μL , which consistently results in vesicles eluting in the 1.5 mL EV zone.

Loss of vesicles occurs with sample volumes over 500 μL as the vesicles elute over a large volume. EVs collected outside of the 1.5 mL EV zone are not recommended for downstream analysis where high purity is required.




Figure 6: Vesicle elution profiles for loading of plasma from 100 to 2000 μL .

3.7.2 Effect of Resin Type on Protein Elution Profile

The EV zone on a qEVOriginal contains very little protein, with protein levels increasing in later volumes, as shown in [Figure 7](#). Higher protein levels for the qEVOriginal-35 are due in part to higher recovery of smaller EVs in the EV zone ([refer to Fig.2](#)).

3.7.3 Effect of Sample Input Volume on EV Dilution and Recovery Rate

The recovery rate of input particles is dependent on the target particle size and the qEV SMART column series used. Refer to the comparison between qEV/35nm and qEV/70nm series above, [Figures 2-4](#). The dilution factor depends on the sample loading volume and EV zone volume pooled.




Figure 7: Percentages of protein cf. starting quantity of protein from loading 0.5mL of plasma onto a qEVOriginal. Pink bars are the EV zone. qEVOriginal -70 bars are dark pink and dark blue. qEVOriginal -35 bars are light pink and light blue.

The following section provides instructions for the manual use of qEV SMART columns. For use of qEV SMART columns with the Automatic Fraction Collector (AFC) instrument, please see the full AFC

4.1 Operational Recommendations

The following recommendations are provided to ensure optimal performance of the qEV SMART column:

- **Centrifuge samples prior to loading onto the column.** To avoid clogging of column filters, it is recommended to filter or centrifuge the biological sample to remove large particulate matter.
 - Centrifuge samples at 1,500g for 10 minutes to remove any cells and large particles.
 - Gently move the supernatant to a new tube and centrifuge again at 10,000g for 10 min.
 - For microvesicle isolation, use lower g-forces for the second centrifugation step.
- **Samples can be concentrated before application to the column or after isolation if needed.** It is possible to concentrate samples both before and/or after use of the qEV SMART column, however Izon offers multiple column sizes to reduce the need for pre-analytical sample concentration. If concentration protocols are needed, please consider the following recommendations:

- Concentration of some sample types may result in the formation of precipitates and protein aggregates, especially for urine samples. Concentrated samples should be centrifuged at 10,000g for 10 minutes prior to loading onto a qEV SMART column.
 - Izon recommends using Merck Millipore concentration devices (Amicon® Ultra Centrifugal filters; C7715). Use according to manufacturer's recommendations.
 - Concentration of samples after purification with qEV may result in the loss of some EVs on the membrane.
- **Single-use columns are advisable where the vesicles will be analysed for nucleic acids.** Use of a single-use column, such as the Izon qEVsingle, will reduce the possibility of cross-contamination.
- **Ensure that the sample buffer has been prepared appropriately.** To maintain the functionality of EVs, the flushing buffer should be of the same temperature as the sample buffer. SEC can also be used to exchange the buffer of a sample.
- Sample buffer temperature should be within the operational temperature of 18–24°C (65–75°F).
 - Sample buffers should be degassed and room temperature to avoid air bubbles forming in the gel bed. Rapid changes in temperature, for example removing packed columns from a cold room and applying buffer at room temperature, can introduce air bubbles in the packed bed, resulting in poorer separation.
 - Use a buffer with an ionic strength of 0.15 M or greater to avoid any unwanted ionic interactions between the solute molecule and the matrix.
 - Only use freshly filtered (0.22 µm) buffer to avoid introducing particulate contamination.
 - qEV SMART columns come equilibrated in filtered PBS containing < 0.1% w/v sodium azide.

4.2 Column Setup and Equilibration

1. Equilibrate the column and the sample buffer to be within the operational temperature range of 18-24°C.



Do not remove the column caps until the column has reached operational temperature.



Sample buffers should be degassed and room temperature to avoid air bubbles forming in the gel bed. Rapid changes in temperature, for example removing packed columns from a cold room and applying buffer at room temperature, can introduce air bubbles in the packed bed, resulting in poorer separation.

2. Carefully remove the top cap only and attach the column in an upright position to stand ready for use. qEVoriginal racks and the Automatic Fraction Collector (AFC) are available from <https://store.izon.com>.
3. Remove the bottom cap and allow the buffer to start running through the column.
4. Attach the buffer reservoir to the top of the column.
5. Flush the column with at least one column volume of sample buffer. If an elution buffer other than PBS is to be used, equilibrate the column with at least 3 column volumes of the new buffer.



Only use freshly filtered (0.22 µm) buffer to avoid introducing particulate contamination.

4.3 Sample Loading

1. To avoid clogging of column filters, it is recommended to filter or centrifuge the biological sample to remove large particulate matter. See Section 4.1: Operational Recommendations for more information.
2. Continue to allow buffer to run through the column. The column will stop flowing when all of the buffer has entered the loading frit.
3. Load the prepared centrifuged sample volume onto the loading frit.
4. Immediately start collecting the void volume (this includes the sample volume).
5. Allow the sample to run into the column. The column will stop flowing when all of the sample has entered the loading frit.
6. Top up the column with buffer and continue to collect the void-volume.
7. To collect accurate volumes, only load the required volume to the top of the column, wait for the volume to run through and repeat.



Different samples may give slightly different elution profiles and purity, hence an initial measurement of EV concentration and protein contaminants in collected fractions is recommended.



To ensure accurate EV separation and elution avoid stopping the column flow during the run.

4.4 Column Flush and Storage

1. After all the desired fractions have been collected, flush the column with at least 1.5 column volumes of buffer before loading another sample.
2. If storing the column for future use, flush with buffer containing a bacteriostatic agent (e.g. 0.05 % w/v sodium azide).
3. Store the column at +4 to +8 °C.

5.1 Column Cleaning and Sanitisation

Sanitise and remove precipitated proteins, non-specifically bound proteins and lipoproteins by washing the column with 0.5 mL of 0.5 M NaOH, then flush with buffer until the pH of the eluted buffer is the same as the starting wash buffer pH. The pH will return to neutral after about 2–3 column volumes of wash buffer.

5.2 Protocols for EV Isolation from Common Sources

5.3 EV Analysis Using TRPS

Izon recommends TRPS analysis for determination of particle size, concentration, and zeta potential. The Izon Reagent Kit includes coating solutions for pre-coating the pore, minimising non-specific binding and provides for stable and accurate sizing and concentration analysis.

For TRPS analysis of the EVs, Izon recommends an initial dilution of 1/5 or 1/10 in electrolyte. Optimise the dilution to achieve a rate at the highest operating pressure of approximately 200 to 1600 particles per minute to avoid pore blockage.

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (4232)49-28-31
Владикавказ (8672)28-90-48
Владимир (4922) 49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-61-73
Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
Иваново (4932)77-34-06
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4612)72-03-81
Калуга (4842)92-25-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новыйск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сыктывкар (8212)25-95-17
Сургут (3462)77-98-35
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31